

Technical Specifications: Timecode & Sound for Cameras

Brand	Model	Minimum Firmware	TC in	Audio in	Menu configuration
SONY	FX 3	v 3.0	Micro-USB	Mini-Jack / XLR-3	Menu > 7 TC/UB > Timecode Run > Free Run
	FX 30	v 3.0	Micro-USB	Mini-Jack	Menu > 7 TC/UB > Timecode Run > Free Run
	FX 6		BNC	XLR	TC/Media > Timecode > Mode: Preset > Run: Free Run TC/Media > TC Display > Display Select: Timecode Switch TC IN/OUT > IN
	FX 9		BNC	XLR	TC/Media > Timecode > Mode: Preset > Run: Free Run TC/Media > TC Display > Display Select: Timecode Switch TC IN/OUT > IN
	PXW - FS 7		BNC (Extensión XDCA-FS7)	XLR	TC/Media > Timecode > Mode: Preset > Run: Free Run TC/Media > TC Display > Display Select: Timecode Switch TC IN/OUT > IN
	Venice		BNC	XLR-5	TC/Media > Timecode > Mode: Preset > Run: Free Run TC/Media > TC Display > Display Select: Timecode Switch TC IN/OUT > IN
	A1	v 5.0	Minijack // Micro-USB	Mini-Jack	Menu > TC/UB > Timecode Run > Free Run Setup>Display>TC/UB Disp. Setting>TC
	ALPHA 7S III	v 3.0	Minijack // Micro-USB	Mini-Jack	Menu > TC/UB > Timecode Run > Free Run Setup>Display>TC/UB Disp. Setting>TC
	ALPHA 7S IV		AUDIO TC	Mini-Jack	Menu > TC/UB > Timecode Run > Free Run Setup>Display>TC/UB Disp. Setting>TC
BLACKMAGIC	Pocket		Mini-Jack	Mini-Jack	Monitor > Overlays > Timecode Display

Brand	Model	Minimum Firmware	TC in	Audio in	Menu configuration
	PYXIS 6K		BNC / Mini-Jack / Mini-XLR	Mini-Jack / Mini-XLR	TC/Media > Timecode > Mode: Preset > Run: Free Run TC/Media > TC Display > Display Select: Timecode Switch TC IN/OUT > IN
	URSA Mini		BNC	Mini-Jack / 2xXLR-3	
PANASONIC LUMIX	DC-S1H		Flash Synchro Socket		
	GH5S		Mini-Jack / 2xXLR-3		
	GH6		BNC Conversion cable	Mini-Jack / 2xXLR-3	<u>Com sincronitzar</u>
RED	EPIC		LEMO 4-pin 0B		
	KOMODO (X)		LEMO 9-pin 1B EXT	Mini-Jack	Audio/TC > Timecode Source > External Audio/TC > Timecode Display Mode > TOD
	V RAPTOR		LEMO 9-pin 1B EXT	LEMO 5-Pin 0B	Audio/TC > Timecode Source > External Audio/TC > Timecode Display Mode > TOD
	V RAPTOR XL		LEMO 5-pin	LEMO 5-Pin 0B	Audio/TC > Timecode Source > External Audio/TC > Timecode Display Mode > TOD
ARRI	ALEXA MINI		LEMO 5-pin 1B (90°)	LEMO 5-pin 0B	Camera Menu > TC > Options > Source: Ext. LTC Mode: Free Run Generator: Regen
	ALEXA MINI LF		LEMO 5-pin 1B (NO 90°)	LEMO 6-pin 1B	Camera Menu > TC > Options > Source: Ext. LTC / Mode: Free Run / Generator: Regen

Brand	Model	Minimum Firmware	TC in	Audio in	Menu configuration
CANON	ALEXA 35		LEMO 5-pin 1B	LEMO 6-pin 1B	Menu > System > Sensor > Genlock Sync > Timecode Home > TC > Options > Run Mode: Free Run / Mode: Regen / Count Mode: Non-Dropframe
	AMIRA		BNC	XLR 5-pin / 2 XLR 3-pin	Home > Options > TC BNC mode > TC in Home > TC > Options > Free run, Regen, LTC in Home > TC > Options > Count mode
	C 70		BNC	2 TA3 / Mini-Jack	Menu > System Setup > TC In/Out: In / Time Code Mode: Preset / Time Code Run: Free Run
	C 80		BNC	Mini-Jack	Menu > System Setup > TC In/Out: In / Time Code Mode: Preset / Time Code Run: Free Run
	EOS R5C		DIN 1.0/2.3	Mini-Jack / XLR	24 fps (Tentacle) = 23.98P & 24P (Canon R5C) 25 fps (Tentacle) = 25P, 50i & 50P (Canon R5C) 30 fps (Tentacle) = 29.97P (Canon R5C)
	C100		AUDIO TC	Mini-Jack / 2 XLR	
	C200		AUDIO TC	Mini-Jack / 2 XLR	
	C300		BNC	Mini-Jack / 2 XLR	
	C400		DIN 1.0/2.3	Mini-Jack / 2 mini-XLR	
	C500		BNC	Mini-Jack / 2 XLR	
GO PRO	HERO 7 / 8 / 9 / 10 / 11 / 12 / 13		Timebar app, QR code		Show the QR code within the GoPro's field of view (small QR code verification on the GoPro screen)

Further Details



Adrià Smilges Nieto
+34 623 611 357
adrias@reclab.cat

